


AVA Firmware Upgrade

June 28, 2011

To upgrade the firmware version in AVA perform the following steps:

1. Connect the AVA to your PC using the USB port. If necessary, install the USB drivers from the AVA disc. Power up the AVA.
2. Start the AvaLoad.exe program.



3. Enter the filename for the firmware version to load. This file must be accessible from your PC.
4. Select the COM Port used by your PC, if known. Otherwise, select “probe all”.
5. Click “Program” and follow the on-screen prompts if required.